


ROS 기초 강의

Chapter 11. 실력 상승 노하우

구선생 로보틱스



강의 자료 다운로드



ROS 기초 강의 강의노트

https://drive.google.com/drive/folders/1rRwS2j98HNyj5ls_yVXEGj30ILvMPtrz?usp=drive_link

ROS 실력 상승 노하우

ROS Wiki 활용



동영상 강의 - 마무리

https://youtu.be/3k7oYeeaRhI?si=sq6_lyoWkkxjnszF

Google search results for "nanoscan ros". The search bar shows "nanoscan ros" and the results show approximately 3,070 results in 0.31 seconds. The first result is "sick_safetyscanners - ROS Wiki" with a link to http://wiki.ros.org/sick_safetyscanners. The snippet describes it as a ROS Driver which reads the raw data from the SICK Sa and publishes the data as a laser_scan msg. It also mentions supported sensors like microScan3.

sick_safetyscanners

melodic

noetic

Show EOL distros: ☐

[Documentation Status](#)

Package Summary

✓ Released

✓ Continuous Integration

✓ Documented

Provides an Interface to read the sensor output of a SICK Safety Scanner

- Maintainer status: developed
- Maintainer: Lennart Puck <puck AT fzi DOT de>
- Author: Lennart Puck
- License: ALv2
- Source: git https://github.com/SICKAG/sick_safetyscanners.git (branch: master)

Package Links

[Code API](#)
[Msg/Srv API](#)
[FAQ](#)
[Changelog](#)
[Change List](#)
[Reviews](#)

[Dependencies \(8\)](#)
[Jenkins Jobs \(10\)](#)

로봇 관련 패키지가 필요할 경우 해당 검색어 + ros 를 검색하면
대부분 ros wiki 문서가 있다.

ROS 실력 상승 노하우

Readme 문서 정독

Getting started

The ROS driver will be released as a debian package, and therefore can be installed from binaries or from source.

Prerequisites

- Linux
- Working ROS-Distro
- Correctly setup SICK Safety Scanner
- Connected SICK Safety Scanner and a correctly setup ethernet network. Both the host and the sensor have to be in the same network.


Installation

In the following instructions, replace `<rostdistro>` with the name of your ROS distro (e.g., `kinetic`).

처음보는 패키지 사용시 Readme 문서를 따르는 것이 베스트이다

ROS 실력 상승 노하우

Document 검색



sensor_msgs/LaserScan Message

File: `sensor_msgs/LaserScan.msg`

Raw Message Definition

```
# Single scan from a planar laser range-finder
#
# If you have another ranging device with different behavior (e.g. a sonar
# array), please find or create a different message, since applications
# will make fairly laser-specific assumptions about this data

Header header          # timestamp in the header is the acquisition time of
                        # the first ray in the scan.
                        #
                        # in frame frame_id, angles are measured around
                        # the positive Z axis (counterclockwise, if Z is up)
                        # with zero angle being forward along the x axis

float32 angle_min       # start angle of the scan [rad]
float32 angle_max       # end angle of the scan [rad]
float32 angle_increment  # angular distance between measurements [rad]

float32 time_increment   # time between measurements [seconds] - if your scanner
                        # is moving, this will be used in interpolating position
                        # of 3d points
float32 scan_time        # time between scans [seconds]

float32 range_min        # minimum range value [m]
float32 range_max        # maximum range value [m]

float32[] ranges          # range data [m] (Note: values < range_min or > range_max should be discarded)
float32[] intensities     # intensity data [device-specific units]. If your
                        # device does not provide intensities, please leave
                        # the array empty.
```

ROS 내부의 자료형 및 소스코드를 알고 싶을 시
해당 키워드 + document라고 검색 시 자료가 나온다

ROS 실력 상승 노하우

ROS info 명령어 활용

1) Ros topic 정보

```
$ rostopic info <토픽-이름>
```

2) Ros node 정보

```
$ rosnode info <노드-이름>
```

3) Ros service 정보

```
$ rosnode service <서비스-이름>
```


Info 명령어를 이용하면 패키지를 쉽게 분석할 수 있다.

ROS 실력 상승 노하우

ROS info 명령어 활용



ROS 레퍼런스 소스코드
https://github.com/PigeonSensei/pigeon_ros_tutorial



ROS 소스코드 레퍼런스를 활용하면 쉽게 프로그래밍 가능하다.

감사합니다

구선생 로보틱스

